

CARGADOR TOSHIBA

[Ver producto](#)

Descripción del producto

☒ Input Voltage Range: AC 100V ? 240V

☒ Output Voltage: 19V

☒ Output Current: 3.42A

☒ Power: 65 Watt

Precio: S/55

[Añadir al carrito](#)



Descripción

CABLE PODER INCLUIDO

Compatible Models

Toshiba Satellite A85 Series A85, A85-S107, A85-S1071, A85-S1072.

Toshiba Satellite A80 Series A80, A80-111, A80-115, A80-116, A80-117, A80-121, A80-122, A80-127, A80-129, A80-131, A80-135, A80-142, A80-154, A80-157, A80-S178TD.

Toshiba Satellite A100 Series A100, A100-S2211TD, A100-S2311TD, A100-S3211TD, A100-S8111TD, A100-ST3211, A100-ST8211.

Toshiba Satellite A105 Series A105, A105-S101, A105-S101X, A105-S271, A105-S271X, A105-S361, A105-S361X, A105-S1013, A105-S1014, A105-S171, A105-S171X, A105-S1711, A105-S1712, A105-S2001, A105-S2021, A105-S2071, A105-S2101, A105-S2712, A105-S2713, A105-S2716, A105-S2717, A105-S2719, A105-S3611, A105-S4001, A105-S4002, A105-S4004, A105-S4011, A105-S4014, A105-S4021, A105-S4024, A105-S4254, A105-4324, A105-S4334, A105-S4344, A105-S4384.

Toshiba Satellite A110 Series A110, A110-101, A110-110, A110-133, A110-195, A110-203, A110-212, A110-225, A110-228, A110-253, A110-294, A110-S111, A110-ST1111.

Toshiba Satellite L10 Series L10, L10-100, L10-101, L10-102, L10-103, L10-107, L10-108, L10-114, L10-117, L10-118, L10-119, L10-121, L10-123, L10-125, L10-130, L10-132, L10-144, L10-151, L10-154, L10-186, L10-190, L10-192, L10-193, L10-194.

Toshiba Satellite L15 Series L15, L15-S104, L15-S107, L15-S1041, L15-S1071.

Toshiba Satellite L20 Series L20, L20-S310TD, L20-SP231.

Toshiba Satellite L25 Series, L25, L25-S119, L25-S121, L25-S1192, L25-S1193, L25-S1194, L25-S1195, L25-S1196, L25-S1211, L25-S1212, S25-S1213, L25-S1214, L25-S1215, L25-S1216, L25-S121.

Toshiba Satellite L35 Series L35, L35-S1054, L35-S2151, L35-S2161, L35-S2171, L35-S2174.

Toshiba Satellite M30X Series, M30X-40 M30X-60 M30X-80 M30X-S114 M30X-S1592ST M30X-1593ST M30X-S171ST M30X-S181 M30X-S191 M30X-214 M30X-S221 M30X-S234 M30X-SP114.

Toshiba Satellite M35X Series M35X, M35X-S109, M35X-S111, M35X-S114, M35X-S149, M35X-S161, M35X-S163, M35X-S309, M35X-S311, M35X-S329, M35X-S349, M35X-S1141, M35X-S1142, M35X-S1143, M35X-S1491, M35X-S1492, M35X-S1611, M35X-S1631, M35X-S3091, M35X-S3111, M35X-S3112, M35X-S3291, M35X-S3491.

Toshiba Satellite M60 Series M60, M60-112, M60-131, M60-139, M60-148, M60-163, M60-BK3, M60-S811TD, M60-S811ST, M60-S6111TD, M60-S8112TD, 60-S8112ST.

Toshiba Satellite M65 Series M65, M65-S809, M65-S8091, M65-S8092, M65-S821, M65-S8211, M65-S8213, M65-S9062, M65-S9063, M65-S9064, M65-S9065, M65-S909, M65-S9091, M65-S9092, M65-S9093, M65-S9094.

Toshiba Satellite 1000 Series.

Toshiba Satellite 1100 Series, 1100-S101, 1105, 1110-S153, 110CT, 1115-S103, 1115-S123.

Toshiba Satellite 1200 Series.

Toshiba Satellite 1130 series.

TOSHIBA Satellite 1600 series.

TOSHIBA Satellite 1700series.

TOSHIBA Satellite 1715XCDS series.

Toshiba Satellite 1900 Series 1900-S305, 1900-OFS, 1900-101.

Toshiba Satellite 1905 Series, 1905-S277, 1905-S301, 1905-S302, 1905-S303, 1905-S304.

TC ACCESORIOS - PERÚ

Accesorios de computo

Toshiba Satellite 1950, 1955 Series, Covers Satellite Models 1950, 1950-801, 1955-S801, 1955-S802, 1955-S803, 1955-S804, 1955-S805, 1955-S806, 1955-S807.

Toshiba Satellite 2430 Series, 2430-S255, 2430-S256.

Toshiba Satellite 2435 Series, 2435-S256.

Toshiba Satellite 3000 Series.

Categorías: [ADAPTADORES \(PC - LAPTO - TV\)](#), [ADAPTADORES CORRIENTE](#)